

KEW 3132A

KEW 3132A - Kyoritsu Analogue Insulation / Continuity Tester

Rating: Not Rated Yet

2-3 Days

★★★★

[Ask a question about this product](#)

Manufacturer [KYORITSU](#)

Description

- Dust and drip proof construction. (designed to IEC 60529 IP54)
- Designed to meet IEC 61010-1 and IEC 61557 safety standard.
- 1mA rated test current at the minimum resistance.
- 200mA measuring current on continuity testing.
- Automatic discharge of circuit capacitance.
(Any charge stored in the circuit under test will be automatically discharged after testing.)
- Live circuit warning buzzer and neon lamp.
- Small and lightweight. Shock resistant new case material.
- AC voltmeter with linear, easy-to-read scale.
- Operates on AA, R6 x 6 dry batteries.

| | |
|---------------------------------------|-----------------------------------------------------------------------------------------|
| Test voltage | 250V/500V/1000V |
| Measuring ranges (Mid-scale value) | 100M?/200M?/400M? (1M?) (2M?) (4M?) |
| Output voltage on open circuit | Rated test voltage+20%, -0% |
| Nominal current | 1mA DC min. |
| Output short circuit current | 1 - 2mA DC |
| Accuracy | 0.1 - 10M?/0.2 - 20M?/0.4 - 40M? (Accuracy Guaranteed Ranges) ±5% of indicated value |

Continuity

| | |
|---------------------------------------|---------------------------|
| Measuring ranges (Mid-scale value) | 3?/500? (1.5?) / (20?) |
| Output voltage on open circuit | 4.1V DC approx. |
| Measuring current | 210mA DC min. |
| Accuracy | ±1.5% of scale length |

AC Voltage

| | |
|------------|---------------------|
| AC Voltage | 0 - 600V AC |
| Accuracy | ±5% of scale length |

General

| | |
|----------------------|--------------------------------------------------------------------------------------------------------------------------------------|
| Safety Standard | IEC 61010-1 CAT III 600V Pollution Degree 2 IEC 61010-2-031 IEC 61557-1/2/4 |
| IP Rating | IEC 60529-IP54 |
| EMC Standard | IEC 61326-1 |
| Power source | R6 (AA) (1.5V) x 6 |
| Dimensions | 106(L) x 160(W) x 72(D)mm |
| Weight | 560g approx. |
| Included Accessories | 7122B (Test leads) Pouch for test leads 8923 (F500mA/600V fuse) x 2 R6 (AA) x 6 9121 (Shoulder Strap) Instruction Manual |