

ALT Load Bank Tester Series

ALT Series - ALTERN Load Bank Tester / Battery Load Tester

Rating: Not Rated Yet

[Ask a question about this product](#)

Manufacturer [ALTERN](#)

Description

ALT Series is a DC load banks feature unique design and excellent performance that will facilitate your work for DC load and battery capacity testing. We offer many different load bank models to cover a wide voltage range from 12V to 480V nominal voltages with current up to 600A. They are applied for users from various industries including telecom, power utility, data center, forklift and others. With its optional DAC, discharge values of EACH cell could be monitored on the load bank screen and PC simultaneously by using the Altern data view software

- Optional wireless DAC enables online monitoring.
- Four sets of conditions for discharge auto shut-down: Discharge time, discharge capacity, string voltage and cell voltage
- Continued discharge available when previous discharge is stop abnormally.
- Parallel connection of two units for higher discharge current.
- Monitoring measurement of other load banks or battery charger.
- Auto sorting for lag-out batteries during discharge.
- Automatic protection upon over-heating and overload.
- Management software for data analysis and report generation.

Please contact us for configuration.